

Electron-beam positive tone resist

gL2000

Ver.7 2015.02.19




GluonLab.

gL2000 now distributed by

MICRO • CHEM


- High speed, high resolution resist
- Tunable develop process
- High resolution developer available
- High dry etch resistance (Superior to PMMA)

Dose margin Developer: gL Developer




100kV 50pA
Pitch150nm/space50nm

gL2000 resolution



Pitch50nm/space16.25nm



Pitch40nm/space12.5nm

Film thickness :60nm 100kV 10pA


Developer :gL Developer @RT × 30sec.

Dot pattern & Donut pattern


Film thickness :230nm 100kV 50pA

Developer :gL Developer @RT 120sec

Dot pattern



Donut pattern




Dry-etching resistance

- Compared to leading competitor

Ar (Argon)


Film thickness loss (nm)



Microwave power : 40 W
Acceleration voltage : 0.4 kV
Ar flow : 1.0 sccm
Ion current : 0.56 mA/cm²

Dry-etching resistance


- Compared to leading competitor and PMMA
 CF_4 (Reactive-ion-etch process)



Etch Selectivity of PMMA, ZEP 250A and gL2000 vs. SiO₂. The difference in etch selectivity values for ZEP 250A and gL2000 is within the margin of error of the measurement.

*** Data courtesy of R. G. Hobbs, M. K. Mondol and K. K. Berggren, Research Laboratory of Electronics, Massachusetts Institute of Technology*

gL2000 Spin curve



gL2000 Line-up

Resist : gL2000-L, M, H

Package Sizes: ▪ 100ml ▪ 946ml (Quart)

Developer : gL Developer (Standard Developer)
: gL Developer HR (High Resolution Developer)
Rinse : gL Rinse
Remover : gL Remover

Available in 4 liter containers



MicroChem Corp. now distributes the gL2000 resists and manufactures the associated ancillaries.